

Universal Button Cell Battery Volt Tester Checker BT-168



Description and Features:

Universal Button Battery Checker Tester BT-16801

Which Batteries to Keep and Which to throw Away,
Place your battery between the two points of the battery tester,
and the easy-to-read display will tell you instantly whether you have a dud,
or if you can eke out another few minutes of battery life.

Checks power level of all 1.5V & 9V batteries

Easy to read, color coded meter indicates power level

Tests 1.5V miniature cells

Three result: red = replace, yellow = low power, green = good

If needle does not move, check that battery is touching both contacts before assuming that it is completely dead.

The battery tester may be used to test the following sizes:

1.5V:

AAA, HP16, MN2400, R03


AA, HP7, MN1500, UM3

C, HP11, MN1400, SP11, LR14, UM2


D, HP2, MN1300, SP2, R20, UM1

9V: PP3, MN1604, 6F22, 006P


1.5v batteries



9v batteries



1.5v miniature cells



NOTE:

The battery tester is activated by the battery being checked. Keep test times as short as possible to avoid unnecessary battery drain.



Specification:

Color: Black

Item size: 110*59*25mm

Net weight: 51g

Package weight: 60g